




ПЕЧЬ ДЛЯ ПИЦЦЫ ТАТРА ТРО 4 NEW




ПОВЕРХ ЕЧЬ ДЛЯ ПИЦЦЫ TATRA TPO 4 NEW

1	Housing	120213	
2	Door Frame	120218	
3	Flue	120144	
4	Door-Complete	120199	
5	Chamber-Complete	120203	
6	Panel	110493	
7	Right Cover	110490	
8	Left Cover	110491	
9	Stone	230019	
10	Heating Element 1150 W	230016	
11	Heating Element 1350 W	230017	
12	Thermometer	220029	
13	Thermostat Button	220024	
14	Light On-Off Switch	220025	
15	Green Indicator Light	220023	
16	Housing Leg	110495	
17	Rear Insulation	110511	
18	Right Insulation	110509	
19	Left Insulation	110510	
20	Horizontal Insulation	110508	
21	Flue Insulation	110338	
22	Pako Switch	220030	
23	Electrical Sheet	110506	
24	Upper Thermocouple Holder	110026	
25	Upper Heating Element Holder	110507	
26	Thermostat	220026	
27	Chamber Light	220031	
28	Power Terminal Holder	110339	

ПЕЧЬ ДЛЯ ПИЦЦЫ TATRA TPO 4 OLD



ПЕЧЬ ДЛЯ ПИЦЦЫ TATRA TPO 4 OLD

1	Housing	E072101	
2	Side Panel	E072104	
3	Left Cover	E072103	
4	Door Frame	E070008	
8	Door complete	E070001	
9	Panel	E072109	
10	Base	E070013	
21	Bracket for Thermostat	E050121	
23	Bracket for Thermostat	E050123	
25	Fixing for Heating Element	E050126	
30	Heating Element (Upper and Lower front ones) 1150 W	CP700-1150WHE	
30.A	Heating Element (Upper and Lower front ones) 1350 W	CP700-1350WHE	
31	Knob, black-chromed for thermostat	E0ANOT235	
32	Green indicator Light,complete	043828	
33	Thermostat 455°C	OT455EGO	
34	Refracter Stone(Italian)	CP700-700.355	
35	Handle with connect part, big	E0BK600N	
37	Connector, 2-poles, ceramic for lamp	CRM057KLMS	
39	Lamp On/Off Switch	A040588	
40	Control Panel Sticker	E015ETKT	
41	Door glass	E049371	
47	Thermometer	E049371	
48	Bracket for hesting element	E000521506	
49	Halogen Lamp w.cover glass, square	E070099	
	Halogen Bulb G9	E015ELCSQ	
51	Therminal box	06061056	
52	Connector with 2 poles	T00133BX	
53	Connector with 3 poles	E0730733	
54	Strain Relief PG21	010578030	